



PART LIST

NO.	CODE NO.	PARTS NAME (ENG)	Q'TY	NO.	CODE NO.	PARTS NAME (ENG)	Q'TY
1	2-001107701	Housing	1	25	2-9284008	Spring Pin	2
2	2-916003510	O-Ring	1	26	2-015107701	Front Plate	1
3	2-030106302	Trigger	1	27	2-9026203	Ball Bearing	1
4	2-004106301	Exhaust Deflector	1	28	2-061107701	Packing	1
5	2-016106301	Washer	1	29	2-022107701	Hammer	2
6	2-927023	Oil Seal	1	30	2-020119801	Hammer Cage	1
7	2-010107701	Pin Valve Rod	1	31	2-023119801	Hammer Pin	2
8	2-002107701	Cone Spring	1	32	2-025119901	Anvil	1
9	2-916015526	O-Ring	1	33	2-916017824	O-Ring	1
10	2-005107703-03	Air Inlet	1	34	2-069103801	Anvil Collar	1
	2-005107703-07	Air Inlet		35	2-026119901	Bushing	1
11	2-031119801	Reverse Lever	1	36	2-027119901	Front Casing	1
12	2-007102702	Spring	1	37	2-91503	Oil Drop	1
13	2-9180318	Steel Ball	1	38	2-9283024-02	Spring Pin	1
14	2-916062520	O-Ring	1	39	2-9282020	Spring Pin	1
15	2-916044520	O-Ring	1	40	2-003106301	Muffler Filter	1
16	2-071119801	Cover	1	41	2-907030	Retaining Ring	1
17	2-049107701	Screw	4				
18	2-061107702	Packing	1				
19	2-9026202	Ball Bearing	1				
20	2-011107701	Rear Plate	1				
21	2-013119801	Rotor	1				
22	2-014107701	Blade	6				
23	2-007107701	Spring	6				
24	2-012107703	Cylinder	1				